

Ag Link, Inc.

P.O. Box 12

Phone: 209-634-8849

www.agmat.com

www.rubberbark.com

13000 Newport Road

Ballico, CA 95303

Fax: 209-634-8704

rob@rubberbark.com

Bender Board Installation for Tree Wells:

1. Dig a slight trench where the boards will be placed. In this example, the Bender Board is replacing another boarder so the trench and fill existed.



2. Put the boards in place lining up the notched corners.



3. Level the boards adjusting the soil height under each as necessary.



4. Back fill all around to set them in place with corners set flush.



5. Install the stakes to secure. 2 per board recommended. Using a mallet, hammer stake to desired height.



6. Insert screws to secure stakes to boards. 2 screws per stake minimum. Easiest with a power tool.



7. Add Rubber Bark™ to desired fill level.

